

The AV Coach

- 1) Mount Lens & Open Iris All the Way
- 2) Place Siemens Star Chart 9' 10" (3m) from Focal Point on Camera Body
- 3) Loosen the Back Focus Knob & Adjust Ring Until Optimal Focus is Reached when Radial Lines Become Sharpest at Widest Zoom
- 4) Zoom In
- 5) Focus on the Chart
- 6) Zoom Out and Check if Focus is Still Good When Wide as Done in #3
- 7) Tighten the Back Focus Knob Once Focus Is Locked In.

